

# **Installation Instructions**

## **Venue Series - Bodega Appendix**

**Use this Appendix with the Anchor Structure**

### **Venue Series Instruction Manual**



Please read all assembly / installation instructions before the installation or removal of this product.





7701 Highway 41 N  
Evansville, IN 47725  
Phone: 812-867-2421  
Fax: 812-867-1429  
1-800-544-4445  
email: [tents@anchorinc.com](mailto:tents@anchorinc.com)  
[www.anchorinc.com](http://www.anchorinc.com)



**Note:** Follow the standard Anchor Venue Assembly Instructions. This structure is assembled in the same manner as the standard structure except as noted.

**VENUE BODEGA SIZES AND CONFIGURATIONS**

**9 METER**





**9 METER**





**9 METER w/Overhang**

## 12 METER





**12 METER**





**12 METER w/Overhang**

## 15 METER




**15 METER**




**15 METER w/ Overhang**


# 18 METER




**18 METER**



**18-9 METER**



**18 METER w/ Overhang**



**18-9 METER w/ Overhang**

## Assembling Arches & Cable Bracing

Follow the instructions in the standard Venue manual except as noted in this illustration.





Figure 5

## **Install Gable End Framing**

Follow the instructions in the standard Venue installation manual except for 12M Structure. The 12M will require an upright-rafter connecting bracket assembly attached to the Bodega Center Rafter.




## **Install Fabric Panels**

Follow the instructions in the standard Venue installation manual except as follows.

Mids will be tensioned as shown.

Gable End has no lace. Pull in and over from one end and tension as shown.



## Venue Bodega with Overhang

